



FIXATIONS OPTIONNELLES



- FR | Equerre de déport
- EN | Offset bracket
- ES | Escuadra de separación
- IT | Fissaggio con staffa offset
- DE | Winkelträger mit Versatz (zum Schrauben)
- NL | Bevestiging met offsetbeugel



- FR | Support sans perçage réglable
- EN | Adjustable no drilling bracket
- ES | Soporte sin necesidad de taladrar ajustable
- IT | Supporto senza foratura regolabile
- DE | Verstellbarer Klemmträger (ohne Bohren)
- NL | Ondersteuning zonder instelbaar boren




- FR | Support sans perçage
- EN | No drilling bracket
- ES | Soporte sin necesidad de taladrar
- IT | Supporto senza trapano
- DE | Klemmträger (ohne Bohren)
- NL | Boorloze standaard



- FR | Guidage équerre sur fenêtre ou mural
- EN | Square guide brackets for window or wall
- ES | Guía en ángulo en la ventana o la pared
- IT | Guida angolare a muro o quadrata
- DE | Spannwinkel für Fensterflügel (zum Schrauben)
- NL | Vierkante of wandhoekgeleider




- FR | Guidage plat sur appui de fenêtre ou sol
- EN | Flat guide brackets for window or floor
- ES | Guía plana en el vierteaguas de la ventana o en el suelo
- IT | Guida piatta su supporto finestra o pavimento
- DE | Spannschuh für Fensterbank (zum Schrauben)
- NL | Platte geleider op raam of vloersteun




- FR | Guidage sans perçage sur ouvrant
- EN | No drilling guide brackets for opening
- ES | Guía sin necesidad de taladrar en la hoja de la ventana all'apertura
- IT | Guida senza foratura all'apertura
- DE | Spannschuh für Fensterflügel (ohne Bohren)
- NL | Begeleiding zonder te boren bij opening

PRECAUTIONS






E* =

- FR | Encombrement du store replié
- EN | Overall dimensions of the raised blind
- ES | Tamaño del estor plegado
- IT | Il disordine della tenda piegata
- DE | Gesamtmaß der Innenjalousie mit gestauchten Lamellen
- NL | Rommel van het opgevouwen zonnescherm



1





4

FR	1* = Déverrouillez 2* = Dépliez / Repliez 3* = Verrouillez 0* = Orientez F* = Dépliez / Orientez / Repliez
EN	1* = Unlock 2* = Lift / Lower 3* = Lock 0* = Turn F* = Lift / Turn / Lower
ES	1* = Desbloquee 2* = Doble / Desdoble 3* = Bloquee 0* = Orientelo F* = Doble / Orientelo / Desdoble
IT	1* = Sbloccare 2* = Aprire / Piegare 3* = Bloccare 0* = Orientare F* = Aprire / Oriente / Piegare
DE	1* = Aufschließen 2* = Entfalten / Falten 3* = Sperren 0* = Orientieren F* = Entfalten / Orientieren / Falten
NL	1* = Ontsluiten 2* = Uitvouwen / Vouwven 3* = Slot 0* = Oriënteren F* = Uitvouwen / Oriënteren / Vouwven